

*SightSaver™ Bulbs* have been discontinued, but you can still derive years of pleasure from your existing *SightSaver™ Lamp* by following these simple steps for replacing the bulb. We recommend a CFL Bulb of at least 30 Watts to maintain the level of lighting you have become accustomed to.

- 
- 
1. Remove old bulb from lamp and discard in a manner suited for Compact Fluorescent Bulbs. Do not place in regular trash.
  2. Unplug you *SightSaver™ Lamp* completely. **Do not proceed with lamp plugged in.**
  3. Find the white bulb basket located at base of socket (see image 1a).
  4. With a pair of needle nose pliers, remove the basket only from the socket. It is common for basket to break during this process. This is not a concern as it can be discarded upon completion.
  5. When basket is removed (see image 1b) your *SightSaver™ Lamp* is now ready to accept a standard CFL, Incandescent or LED Type A, Medium Base bulb.
- 
- 

Image 1a



Image 1b

